

- 1** Remove the temporary while leaving in the multi-unit abutments .
- 2** Select appropriately sized full arch bite registration tray. Correct depth is when the occlusal surface is touching the bottom of the tray, you can trim around the tray to achieve this if necessary. The handle should be level to the tray, not arched.
- 3** Load heavy bodied impression material into tray. Light bodied impression material is too soft. Fill tray half way up for the full length of the tray. Press onto teeth and hold for 2 minutes making sure occlusal surfaces touch the bottom of the tray.
- 4** Remove excess material from around the tray, making sure the top is flat, level with the tray.
- 5** Take two parts putty, one scoop of each, blend together. Load putty on the surface of the tray. Use a thick layer and cover the entire surface. Have patient gently bite down until they attain a comfortable bite and hold in place for 4 minutes.
- 6** Remove the tray from patient's mouth and clean up any excess material from around the tray. Next, remove the handle of the tray.
- 7** Place impression tray back in patient's mouth for measurements. Midline: draw a line down the center from nose to chin. Lip Line: draw across the upper lip.
- 8** Take photos. No smile from front, no smile from side/profile. Exaggerated smile from front, exaggerated smile from side/profile.
- 9** Send bite impression and photos into Digital Dental Fusion at the address below.

Lab slips available at: <https://zirpeek.com/send-case/>



6280 S. Valley View Blvd, #310  
Las Vegas, NV 89149